

Maintenance Above Alumitex® Panels

While standing on Elemex® Alumitex® panels is never recommended, if maintenance needs to take place above these panels, and they need to be stood upon, the following steps should be followed to ensure no damage takes place to the panels.

1. Place 2" rigid insulation down upon the panels. Mark the panel joints as the insulation is put down.



12" rigid foam

2. Place $\frac{1}{4}$ " plywood/OSB on top of the rigid insulation. Again, mark the panel joints as the plywood/OSB is put down.



$\frac{1}{4}$ " plywood/OSB

3. Whenever possible, stay on the panel joints. They are the strongest part of the panel, and carry the lowest risk of damage.

4. Perform maintenance work.

5. Remove plywood/OSB and 2" rigid insulation.

6. Wipe down panels to remove any debris.